

ULTRA-EZZ III CONTROL FEATURES

This switch is a combination of both up buttons. It brings the foot rest in, brings the back up to a seated position and lifts the chair to the standing position.

This switch brings the back up

This switch lowers the back.

This switch increases the back massage intensity.

This switch increases the lower body leg massage intensity.

Automatic timer setting for the massage 15, 30, or 60 minutes.

This switch brings the foot rest in and lifts the chair to the standing position.

This switch brings the footrest out and lifts the legs and feet.

This switch is a combination of both down buttons, it brings the foot rest out, lifts the legs, and lowers the back

This switch decreases the upper body back massage intensity.

This switch decreases the lower body leg massage intensity.

Automatic timer setting for heat pad, 15, 30, or 60 minutes.

Ultra-Ezz III Miracle Motion Wassage

MASSAGE INTENSITY

POOT

15 30 60

HEAT

PAD

15 30 60

MASSAGE

TIMER

This is for the Model 5555 (Two Motor) with Ultra-Ezz III Massage